



Remove the door and place the outside surface face down on a clean padded work surface.

1. Evenly distribute the seal around the perimeter of the door glass by pressing the seal at the 6 points indicated by red arrows
2. Press inward between the red arrows – as indicated by blue arrows.

It is better to bunch the seal rather than stretch the seal while working it onto the glass edge.

